

	Марка	Модель	Тел Книга SIM/Тел	Набор номера	Интернет	Определение Номера
Nokia	Nokia	2630	+	+	+	+ / +
	Nokia	2660	+	+	+	+ / +
	Nokia	2760	+	+	+	+ / +
	Nokia	3109	+	+	+	+ / +
	Nokia	3110 classic	+	+	+	+ / +
	Nokia	3120	+	+	+	+ / +
	Nokia	3230	+	-	+	+ / +
	Nokia	3250	+	-	+	+ / +
	Nokia	3500 classic	+	+	+	+ / +
	Nokia	3600S	+ / +	+	+	+ / +
	Nokia	5200	+	+	+	+ / +
	Nokia	5300 XpressMusic	+	+	+	+ / +
	Nokia	5310 XpressMusic	+	+	+	+ / +
	Nokia	5500	+	-	+	+ / +
	Nokia	5610 XpressMusic	+	+	+	+ / +
	Nokia	5700 XpressMusic	+	-	+	+ / +
	Nokia	6021	+	+	+	+ / +
	Nokia	6085	+	+	+	+ / +
	Nokia	6103	+	+	+	+ / +
	Nokia	6110 Navigator	+	-	+	+ / +
	Nokia	6111	+	+	+	+ / +
	Nokia	6120 classic	+	-	+	+ / +
	Nokia	6125	+	+	+	+ / +
	Nokia	6126h	+	+	+	+ / +
	Nokia	6131	+	+	+	+ / +
	Nokia	6151	+	+	+	+ / +
	Nokia	6230	+	+	+	+ / +
	Nokia	6230i	+	+	+	+ / +
	Nokia	6233	+	+	+	+ / +
	Nokia	6234	+	+	+	+ / +
	Nokia	6255i	+	+	-	+ / +
	Nokia	6260	+	-	+	+ / +
	Nokia	6267	+	+	+	+ / +

Nokia	6268	+	+	-	+ / +
Nokia	6270	+	+	+	+ / +
Nokia	6280	+	+	+	+ / +
Nokia	6288	+	+	+	+ / +
Nokia	6290	+	-	+	+ / +
Nokia	6300	+	+	+	+ / +
Nokia	6310i	+	+	+	+ / +
Nokia	6500c	+	+	+	+ / +
Nokia	6555	+ / +	+	+	+ / +
Nokia	6630	+	-	+	+ / +
Nokia	6670	+	-	+	+ / +
Nokia	6680	+	-	+	+ / +
Nokia	6681	+	-	+	+ / +
Nokia	6682	+	-	+	+ / +
Nokia	6810	+	+	+	+ / +
Nokia	6820	+	+	+	+ / +
Nokia	6822	+	+	+	+ / +
Nokia	7280	+	+	+	+ / +
Nokia	7370	+	+	+	+ / +
Nokia	7373	+	+	+	+ / +
Nokia	7390	+	+	+	+ / +
Nokia	7500	+	+	+	+ / +
Nokia	7600	+	+	+	+ / +
Nokia	7610	+	-	+	+ / +
Nokia	7710	+	-	+	+ / +
Nokia	7900 Prism	+	+	+	+ / +
Nokia	8600 Luna	+	+	+	+ / +
Nokia	8800	+	+	+	+ / +
Nokia	9300	+	-	+	+ / +
Nokia	9300i	+	-	+	+ / +
Nokia	9500	+	-	+	+ / +
Nokia	E50	+	-	+	+ / +
Nokia	E51	+	-	+	+ / +
Nokia	E61	+	-	+	+ / +
Nokia	E61i	+	-	+	+ / +
Nokia	E62	+	-	+	+ / +

	Nokia	E65	+	-	+	+ / +
	Nokia	E66	+	-	+	+ / +
	Nokia	E71	+	-	+	+ / +
	Nokia	E90	- / +	-	+	+ / +
	Nokia	N70	+	-	+	+ / +
	Nokia	N71	+	-	+	+ / +
	Nokia	N72	+	-	+	+ / +
	Nokia	N73	+	-	+	+ / +
	Nokia	N75	+	-	+	+ / +
	Nokia	N76	+	-	+	+ / +
	Nokia	N80	+	-	+	+ / +
	Nokia	N81	+	-	+	+ / +
	Nokia	N82	+	-	+	+ / +
	Nokia	N90	+	-	+	+ / +
	Nokia	N91	+	-	+	+ / +
	Nokia	N93	+	-	+	+ / +
	Nokia	N95	+	-	+	+ / +
Sony Ericsson	Sony Ericsson	C702	+	+	+	+ / +
	Sony Ericsson	C902	+	+	+	+ / +
	Sony Ericsson	C905	+ / +	+	+	+ / +
	Sony Ericsson	D750i	+	+	+	+ / +
	Sony Ericsson	F305	+ / +	-	+	+ / +
	Sony Ericsson	G502	+	+	+	+ / +
	Sony Ericsson	G700	+	+	+	+ / +
	Sony Ericsson	G900	+	+	+	+ / +
	Sony Ericsson	K510i	+	+	+	+ / +
	Sony Ericsson	K530i	+	+	+	+ / +
	Sony Ericsson	K550i	+	+	+	+ / +
	Sony Ericsson	K600i	+	+	+	+ / +
	Sony Ericsson	K608i	+	+	+	+ / +
	Sony Ericsson	K610i	+	+	+	+ / +
	Sony Ericsson	K618i	+	+	+	+ / +
	Sony Ericsson	K660i	+	+	+	+ / +
	Sony Ericsson	K700i	+	+	+	+ / +

Sony Ericsson	K750i	+	+	+	+ / +
Sony Ericsson	K770i	+	+	+	+ / +
Sony Ericsson	K790c	+	+	+	+ / +
Sony Ericsson	K800i	+	+	+	+ / +
Sony Ericsson	K810i	+	+	+	+ / +
Sony Ericsson	K850i	+	+	+	+ / +
Sony Ericsson	M600i	+	+	+	+ / +
Sony Ericsson	P1i	+	+	+	+ / +
Sony Ericsson	P910i	+	-	+	+ / +
Sony Ericsson	P990i	+	+	+	+ / +
Sony Ericsson	S302				
Sony Ericsson	S500i	+	+	+	+ / +
Sony Ericsson	S700i	+	+	+	+ / +
Sony Ericsson	S710a	+	+	+	+ / +
Sony Ericsson	T610	+	+	+	+ / +
Sony Ericsson	T616	+	+	+	+ / +
Sony Ericsson	T630	+	+	+	+ / +
Sony Ericsson	T637	+	+	+	+ / +
Sony Ericsson	T650i	+	+	+	+ / +
Sony Ericsson	V600i	+	+	+	+ / +
Sony Ericsson	V800	+	+	+	+ / +
Sony Ericsson	W300i	+	+	+	+ / +
Sony Ericsson	W302	+	-	-	+ / +
Sony Ericsson	W550i	+	+	+	+ / +
Sony Ericsson	W550c	+	+	+	+ / +
Sony Ericsson	W580i	+	+	+	+ / +
Sony Ericsson	W595	+ / +	+	+	+ / +
Sony Ericsson	W610i	+	+	+	+ / +
Sony Ericsson	W660i	+	+	+	+ / +
Sony Ericsson	W700i	+	+	+	+ / +
Sony Ericsson	W760i	+	+	+	+ / +
Sony Ericsson	W800i	+	+	+	+ / +

	Sony Ericsson	W800c	+	+	+	+ / +
	Sony Ericsson	W810i	+	+	+	+ / +
	Sony Ericsson	W850i	+	+	+	+ / +
	Sony Ericsson	W880i	+	+	+	+ / +
	Sony Ericsson	W890i	+	+	+	+ / +
	Sony Ericsson	W900i	+	+	+	+ / +
	Sony Ericsson	W910i	+	+	+	+ / +
	Sony Ericsson	W950i	-	-	+	+ / +
	Sony Ericsson	W960i	+	+	+	+ / +
	Sony Ericsson	W980	+	+	+	+ / +
	Sony Ericsson	Z1010	+	+	+	+ / +
	Sony Ericsson	Z310i	+	+	+	+ / +
	Sony Ericsson	Z520a	+	+	+	+ / +
	Sony Ericsson	Z520i	+	+	+	+ / -
	Sony Ericsson	Z550i	+	+	+	+ / +
	Sony Ericsson	Z610i	+	+	+	+ / +
	Sony Ericsson	Z750i	+ / +	+	+	+ / +
	Sony Ericsson	Z750a	+ / +	+	-	+ / +
	Sony Ericsson	Z770i	+ / +	+	+	+ / +
	Sony Ericsson	Z800i	+	+	+	+ / +
Moto	Motorola	A1200	+	+	-	+ / +
	Motorola	A630	+	+	+	+ / +
	Motorola	A732	-	-	+	+ / -
	Motorola	E1	+	+	+	+ / -
	Motorola	E1000	+	+	+	+ / +
	Motorola	E1070	+	+	+	+ / +
	Motorola	E398	+	+	+	+ / -
	Motorola	E550	+	+	+	+ / -
	Motorola	E680	-	-	-	+ / -
	Motorola	E680i	-	-	-	+ / -
	Motorola	E770	+	+	+	+ / -
	Motorola	E8	+ / +	-	+	+ / +
	Motorola	KRZR K1	+	+	+	+ / +

	Motorola	KRZR K3	+	+	+	+ / +
	Motorola	L6	+	+	+	+ / N
	Motorola	L7	+	+	+	+ / N
	Motorola	PEBL U6	+	+	+	+ / -
	Motorola	U9	+ / +	-	+	+ / +
	Motorola	RAZR V3x	+	+	+	+ / +
	Motorola	RAZR V6	+	+	+	+ / +
	Motorola	RAZR V8	+	+	+	+ / +
	Motorola	RAZR V9	+	+	+	+ / +
	Motorola	RAZR maxx v11nn	+	+	+	+ / +
	Motorola	RIZR Z3	+	+	+	+ / +
	Motorola	ROKR E2	+	+	-	+ / +
	Motorola	ROKR E6	+	-	+	+ / +
	Motorola	ROKR Z6	+	+	+	- / -
	Motorola	RIZR Z8	-	-	+	+ / -
	Motorola	SLVR L72	+	+	+	+ / +
	Motorola	V3	+	+	+	+ / -
	Motorola	V360	+	+	+	+ / -
	Motorola	V361	+	+	+	+ / -
	Motorola	V3i	+	+	+	+ / -
	Motorola	V500	+	+	+	+ / -
	Motorola	V501	+	+	+	+ / +
	Motorola	V525	+	+	+	+ / -
	Motorola	V547	+	+	+	+ / -
	Motorola	V550	+	+	+	+ / -
	Motorola	V551	+	+	+	+ / -
	Motorola	V600	+	+	+	+ / -
	Motorola	V600i	+	+	+	+ / -
	Motorola	V620	+	+	+	+ / -
	Motorola	V635	+	+	+	+ / -
	Motorola	V80	+	+	+	+ / -
	Motorola	W510	+	+	+	+ / -
	Motorola	Z9n	+ / +	+	-	+ / +
Samsung	Samsung	A707	+	-	+	+ / -
	Samsung	A717	+	-	+	+ / +
	Samsung	A727	+	-	+	+ / +

Samsung	A827	-	-	+	+ / -
Samsung	D357	+	-	+	+ / +
Samsung	D407	+	-	+	+ / -
Samsung	D500	+	-	+	+ / +
Samsung	D508	+	-	+	+ / -
Samsung	D520	+	-	+	+ / -
Samsung	D600	+	-	+	+ / -
Samsung	D608	+	-	+	+ / -
Samsung	D800	+	-	+	+ / +
Samsung	D807	+	-	+	+ / +
Samsung	D828E	+	-	+	+ / -
Samsung	D830	+	-	+	+ / +
Samsung	D838	+	-	+	+ / +
Samsung	D840	+	-	+	+ / +
Samsung	D900	+	-	+	+ / -
Samsung	D900i	+	-	+	+ / +
Samsung	D908	+	-	+	+ / +
Samsung	E250	+	-	+	+ / +
Samsung	E258	+	-	+	+ / +
Samsung	E370	+	-	+	+ / +
Samsung	E530	+	-	+	+ / -
Samsung	E568	+	-	+	+ / -
Samsung	E570	+	-	+	+ / -
Samsung	E598	+	-	+	+ / +
Samsung	E628	+	-	+	+ / -
Samsung	E648	+	-	+	+ / -
Samsung	E720	+	-	+	+ / -
Samsung	E730	+	-	+	+ / -
Samsung	E738	+	-	+	+ / -
Samsung	E740	+	-	+	+ / -
Samsung	E758	+	-	+	+ / -
Samsung	E760	+	-	+	+ / -
Samsung	E770	+	-	+	+ / +
Samsung	E840	+	-	+	+ / -
Samsung	E848	+	-	+	+ / +
Samsung	E878	+	-	+	+ / +

Samsung	E890	+	-	+	+ / +
Samsung	E900	+	-	+	+ / +
Samsung	E908	+	-	+	+ / +
Samsung	E950	+	-	+	+ / +
Samsung	F110	+ / -	-	+	+ / -
Samsung	F210	+	-	+	+ / +
Samsung	F300	+	-	+	+ / +
Samsung	F480	-	-	-	+ / -
Samsung	F490V	+	-	+	+ / +
Samsung	F500	+	-	+	+ / +
Samsung	G608	+	-	+	+ / +
Samsung	G800	+	-	+	+ / +
Samsung	i300	-	-	+	+ / -
Samsung	i320	+	+	+	+ / +
Samsung	i520	-	-	+	+ / -
Samsung	i620	-	-	-	+ / +
Samsung	J200	-	-	+	+ / -
Samsung	J600	+	-	+	+ / +
Samsung	L708	-	-	+	+ / -
Samsung	L760	-	-	+	+ / -
Samsung	M310	+	-	+	+ / +
Samsung	M8800	+ / +	+	+	+ / +
Samsung	P300	+	-	+	+ / +
Samsung	P858	+	-	+	+ / -
Samsung	S400i	+	-	+	+ / +
Samsung	S500i	+	-	+	+ / +
Samsung	T339	+ / -	-	-	+ / -
Samsung	T509	+	-	+	+ / -
Samsung	T519	+	-	+	+ / +
Samsung	T609	+	-	+	+ / +
Samsung	T619	+	-	+	+ / +
Samsung	T629	+	-	+	+ / +
Samsung	T719	+	-	+	+ / +
Samsung	T809	+	-	+	+ / -
Samsung	U100	+	-	+	+ / +
Samsung	U308	+	-	+	+ / +

	Samsung	U600	+	-	+	+ / +
	Samsung	U700	+	-	+	+ / +
	Samsung	X630	+	-	+	+ / +
	Samsung	X680	+	-	+	+ / +
	Samsung	X820	+	-	+	+ / +
	Samsung	X830	+	-	+	+ / +
	Samsung	Z140	+	-	+	+ / +
	Samsung	Z240	+	-	+	+ / +
	Samsung	Z300	+	-	+	+ / +
	Samsung	Z308	+	-	+	+ / N
	Samsung	Z320i	+	-	-	N / N
	Samsung	Z360	+	-	+	+ / +
	Samsung	Z400	+	-	+	+ / +
	Samsung	Z500	+	-	+	+ / N
	Samsung	Z510	+	-	-	N / N
	Samsung	Z548	+	-	+	+ / +
	Samsung	Z560	+	-	+	+ / +
	Samsung	Z630	+	-	+	+ / +
	Samsung	Z720	+	-	+	+ / +
Siemens	Siemens	CX75	+	+	+	+ / -
	Siemens	M75	+	+	+	+ / +
	Siemens	S65	+	+	-	+ / -
	Siemens	SK65	+	+	+	+ / +
	Siemens	SL75	+	+	+	+ / -
Sharp	Sharp	703SH	+	-	-	+ / -
	Sharp	903SH	+	-	-	+ / -
	Sharp	GXT15	+	+	+	+ / -
	Sharp	GXT25	+	+	+	+ / -
	Sharp	GXT300	+	+	+	+ / -
	Sharp	SX813	+	-	+	+ / +
	Sharp	WX-T81	+	-	+	+ / +
	Sharp	WX-T82	+	-	+	+ / -
LG	LG	CE110	-	-	-	+ / -
	LG	CU515	+ / -	-	+	+ / +
	LG	KC910	+ / +	-	+	+ / +
	LG	KE290	+	-	+	+ / -

	LG	KE600	+	-	+	+ / +
	LG	KE800	+	-	+	+ / +
	LG	KE820	-	-	+	+ / -
	LG	KE850	-	-	+	+ / -
	LG	KE970	-	-	+	+ / -
	LG	KF310	+	-	+	+ / -
	LG	KS20	-	-	-	+ / -
	LG	KU380	-	-	+	+ / -
	LG	KU800	-	-	+	+ / -
	LG	KU970	+	-	+	+ / +
	LG	KU990 Viewty	-	-	-	+ / -
	LG	HB620T	+	-	+	+ / -
	SAGEM	myX6-2	+	+	+	+ / N
	SAGEM	my301X	+	+	+	+ / +
	SAGEM	my501X	+	+	+	+ / N
	SAGEM	my700X	+	+	+	+ / N
Toshiba	Toshiba	803	-	-	+	+ / N
	Toshiba	PORTEGE G500	+	+	-	+ / +
Panasonic	Panasonic	VS6	+	+	+	+ / -
	Panasonic	VS7	+	+	-	+ / -
	Panasonic	X800	+	+	+	+ / -
BlackBerry	BlackBerry	7100g	+	-	-	+ / +
	BlackBerry	7130g	+	-	-	+ / +
	BlackBerry	7290	+	-	-	+ / +
	BlackBerry	8100	+	-	+	+ / +
	BlackBerry	8110	- / +	+	-	+ / +
	BlackBerry	8120	- / +	+	+	+ / +
	BlackBerry	Pearl 8130	+	+	-	+ / +
	BlackBerry	8220	- / +	+	-	+ / +
	BlackBerry	8300	+	+	+	+ / +
	BlackBerry	8310	- / +	+	-	+ / +
	BlackBerry	8320	+	+	+	+ / +
	BlackBerry	Curve 8330	+	+	-	+ / +
	BlackBerry	8700g	+	+	-	+ / +
	BlackBerry	8800	+	-	+	+ / +
	BlackBerry	8820	- / +	+	+	+ / +

BlackBerry	8830	- / +	+	-	+ / +
Dopod	586W	+	+	-	+ / +
Dopod	CHT 9000	+	+	-	+ / -
Dopod	S300	+	+	-	+ / +
Dopod	838	+	+	-	+ / +
HTC	P3300	+	+	-	+ / +
HTC	P3600	+	+	-	+ / +
HTC	SMT5800	-/+	+	-	+ / +
HTC	Touch	+	+	-	+ / +
HTC	Touch Dual	+	+	-	+ / +
HTC	Touch Cruise	+	+	-	+ / +
HTC	Touch Pro	+/+	+	-	+ / +
HTC	Touch HD	+ / +	+	-	+ / +
HTC	Shadow	+ / +	+	-	+ / +
HTC	Wing	+ / +	+	-	+ / +
HTC	HTC TyTN II	+	+	-	+ / +
HTC	Diamond	+	+	-	+ / +
HTC	Dash	+	+	-	+ / +
HTC	Mogul XV6800	+	+	-	+ / -
HP	iPAQ 6365	-	-	-	+ / -
HP	iPAQ rw6828	+	+	+	+ / +
HP	iPAQ 912	+/+	+	-	+ / +
Apple	iPhone 2G	+	+	-	+ / +
Apple	iPhone 3G	+	+	-	+ / +
O2	Xda Stealth	+	+	-	+ / +
O2	Xda Atom	+	+	+	+ / -
O2	Xda IQ	+	+	+	+ / -
ETEN	X500	+	+	-	+ / +
ETEN	G500	+	+	-	+ / +
Palm	Centro	+	+	-	+ / +
Motorola	Q9	+	-	+	+ / +
Pantech	PG3500	-	-	-	+ / -
Sony Ericsson	X1	+ / +	+	-	+ / +
Samsung	i325	N / +	+	-	+ / +
Samsung	i600	-	-	-	+ / -
Samsung	i607	-	-	-	+ / -

	Samsung	i608	+	-	-	+ / -
	Samsung	i760	N / +	+	-	+ / +
	Samsung	i770	N / +	+	-	+ / +
	Samsung	i780	+ / +	+	-	+ / +
	LG	Incite CT810	-	-	-	+ / -
CDMA	LG	KG90c	-	-	-	+ / -
	LG	LX150	-	-	-	+ / -
	LG	LX160	-	-	-	+ / -
	LG	LX350	-	-	-	+ / -
	LG	VX5300	+	+	-	+ / -
	LG	VX5400	+	+	-	+ / -
	LG	VX8100	+	+	-	+ / -
	LG	VX8300	+	+	-	+ / -
	LG	VX8350	+	+	-	+ / -
	LG	VX8500	+	+	-	+ / -
	LG	VX8550	+	+	-	+ / -
	LG	VX8560	+	+	-	+ / -
	LG	VX8600	+	+	-	+ / -
	LG	VX8700	+	+	-	+ / -
	LG	VX8800	+	+	-	+ / -
	LG	VX9100	+	+	-	+ / -
	LG	VX9400	+	+	-	+ / -
	LG	Dare VX9700	+	+	-	+ / -
	LG	VX9800	-	-	-	+ / -
	LG	VX9900	+	+	-	+ / -
	LG	VX10000	+	+	-	+ / -
	LG	Rumor	-	-	-	+ / -
	LG	MUZIQ	-	-	-	+ / -
	Samsung	A303	-	-	-	+ / -
	Samsung	A503	-	-	-	+ / -
	Samsung	A513	+	-	-	+ / -
	Samsung	A900	+	+	-	+ / -
	Samsung	A930	-	-	-	+ / -
	Samsung	A990	+	-	-	+ / -
	Samsung	M500	+	+	-	+ / -
	Samsung	M540(Rant)	-	+	-	+ / -

Samsung	M610	+	+	-	+/-	
Samsung	M620	+	+	-	+/-	
Samsung	M630	-	+	-	+/-	
Samsung	M800(Instinct)	+	+	-	+/-	
Samsung	u410	-	-	-	+/-	
Samsung	u540	+	-	-	+/-	
Samsung	u550	+	+	-	+/-	
Samsung	u620	+	-	-	+/-	
Samsung	u740	+	+	-	+/-	
Samsung	u900	+	+	-	+/-	
Motorola	KRZR K1m	+	+	-	+/-	
Motorola	V3c	+	+	-	+/-	
Motorola	V3m	+	+	-	+/-	
Motorola	V710	-	-	-	+/-	
Motorola	V9m	+	+	-	+/-	
Nokia	2366i	+	+	-	+/-	
Nokia	6205	-	+	-	+/-	
Toshiba	902T	-	-	-	+/-	
JAPAN	Nokia	N73(705NK)	+	-	-	+/-
Toshiba	911T	-	-	-	+/-	
Toshiba	912T	-	-	-	+/-	
Toshiba	920T	-	-	-	+/-	
Toshiba	921T	-	-	-	+/-	
SHARP	811SH	+	-	-	+/-	
SHARP	812SH	+	-	-	+/-	
SHARP	812SHsII	+	-	-	+/+	
SHARP	904SH	+	-	-	+/-	
SHARP	910SH	+	-	-	+/-	
SHARP	912SH	+	-	-	+/-	
SHARP	913SHG	+	-	-	+/-	
SHARP	920SH	+	-	-	+/-	
SHARP	921SH	-	-	-	+/-	
SAMSUNG	707SC	+	-	-	+/-	
SAMSUNG	707SCII	+	-	-	+/-	
SAMSUNG	709SC	+	-	-	+/-	
SAMSUNG	805SC	+	-	-	+/-	

Panasonic	705P	+	-	-	+/-
Panasonic	705Px	+	-	-	+/-
Panasonic	810P	+	-	-	+/-
Panasonic	820P	+	-	-	+/-
HTC	X01HT	+	+	-	+/-
HTC	X02HT	+	+	-	+/-